



CAUTION: Rectify coil utilizes 22VDC coils with AC to DC rectifier. Do not use relay without rectifier. Replace with factory authorized parts only.  
 24VAC Class 2 power source must not exceed 26.4VAC under any primary input voltage condition per UL/NEC

NOTE :

- \* Replace "Service Loop" with SL 6040-063
- \*\* Replace Auto-Reset with Therm-O-Disc type 60TX11-L165.
- \*\*\* 24VAC, Class 2 power source must not exceed 26.4VAC under any primary input voltage condition per UL/NEC.
- \*\*\*\* Power supply wiring per NEC & Local Codes. Suitable for at least 75°C.
- Use copper conductor wiring only.

Model	WHE-1002B
Serial #	
Tag -	
Kilowatts	5.0
Volts-Ph-Hz	240/1/60
Control Volts	24.0
Steps	1
Heater Amps	42.0
Circuit Breaker	60

WHE1002B

Rev. by : M. REEVES  
 Date : 04/05/12

WARREN TECHNOLOGY

Control Wiring -----  
 Power Wiring -----  
 Field Wiring -----